

Vu+ Solo2 Twin Tuner Receiver

1. Download the Firmware update for NZ from http://www.freeviewnz.com/html/help_desk.html
2. Unzip the file and only transfer the folder [vuplus] with contents onto a newly formatted usb stick of about 4Gb (Note very large USB sticks/drives don't work).



Flashing the Receiver.

- Fully power the receiver down via the rocker switch at the rear of the receiver.
- Make sure no USB devices are plugged into the receiver at this point.
- Insert the USB stick containing the image files into one of the USB ports on the receiver.
- Power the receiver on from the rear rocker switch and await instructions.

As your Solo2 starts to power up you should see a prompt on the receivers display asking you to press the power button, at this point you need to press the power button on the front of the receiver, (the blue circles to the left of the front panel, this is a touch sensitive button).

If you don't see the prompt to press the power button but instead see the message "starting" it means that the receiver has not detected the USB stick or image files or both. If this happens start from the beginning or try another USB stick, Image or USB port on the receiver.

If all goes well the flashing process should take approximately 2 minutes to complete, if your chosen image does not contain the "reboot.update" file in the image folder the receiver will sit the with "update complete" message on it's display and will require you to manually power the receiver on and off to reboot then box, if this file is present the receiver will automatically reboot itself once the flashing process is complete.